

Choosing jamb depth

Match the frame profile to the finished wall construction and measured thickness.



Illustration for reference; not to scale.

BEFORE YOU BEGIN

Record the opening number, dimensions, and existing conditions. Keep actual measurements separate from nominal order sizes.

STEP-BY-STEP CHECKLIST

- ☐ 1. Identify whether the wall is stud and drywall, block or masonry, or another construction.
- ☐ 2. Measure the finished wall thickness rather than only the stud or block.
- ☐ 3. Select the frame family that matches the wall construction.
- ☐ 4. Verify nonstandard finishes, tile, or existing conditions with Doors & More before ordering.

Jamb depth follows the finished wall thickness and the type of frame. Drywall and masonry frames use different anchors and profiles. Measure all finished layers and flag unusual conditions so the frame can be reviewed before ordering.

Technical reference: [Tell Manufacturing Spartan frame reference](#)

[Open the technical reference online](#)